



QUICK START GUIDE

MoveAround MA50H



INSTRUCTIONS FOR USING THE LIFT




- 1 Read the operating instructions for understanding safety and functions of the lift.
- 2 Read warning information.
- 3 To insert and disengage the lift's drive mode: Turn the two levers located at the side of the lift pillar. If the levers are hard to turn - gently shake the lift back and forth while turning the levers with careful hand force. **NOTE! Do not use great force.** When the lift is parked - make sure the levers are in the drive mode to prevent the the lift from rolling unintentionally. The levers must be in the drive mode for the platform to be raised / lowered.
- 4 Insert the red main power key switch and turn to "ON".
- 5 Press the joystick power button.
- 6 Drive speed switch: Toggle between high or low driving speed.



- 7** Platform raise / lowering switch: Press the top of the switch to raise and the bottom to lower.
- 8** Driving the lift: Move the joystick in the direction you want to drive.
- 9** Emergency stop: Shuts down the lift's power. Press to activate. Turn clockwise to deactivate.
- 10** Emergency lowering: Pull the handle to lowering the platform.
- 11** Horn.
- 12** After using the lift: Turn the red main power switch key to "OFF", to prevent the batteries from discharging.
- 13** When the lift is not in use: Plug in a extension cable to the lift and connect to a 230 V socket. The lift has a built-in charger that optimally maintains the batteries.



SAFELIFT®

 Made in Sweden

ADDRESS

Safelift Sweden AB
Kvarnvägen 14
SE-352 41 Växjö
Sweden

WEBSITE

www.safelift.se

E-MAIL

info@safelift.se