



QUICK START GUIDE

MoveAround PA35



INSTRUCTIONS FOR USING THE LIFT



- 1 Read the operating instructions for understanding safety and functions of the lift.
- 2 Read warning information.
- 3 Insert the key into the lift's electrical system and turn it to the "ON" position.
- 4 Start button: Press and hold the button for 1 second.
Shutdown: Press and hold the button for 2 seconds.
The lift will shut down automatically if it has not been activated within 10 minutes. Press the up/down button (5) to start again, or press the start button.
- 5 Raising and lowering the platform: Press the top of the button to raise and bottom to lower.
- 6 Emergency stop: Shuts down the lift's power.
- 7 Battery status: Charge the battery if the lights are orange or red.
- 8 Emergency lowering of platform.
- 9 Emergency lowering battery status.



- 10** Tilt indicator (spirit level).
- 11** Anchor point for safety harness.
- 12** Storage compartment for tools.
- 13** Adjustment of automatic wheel locking.
- 14** Rear swivel wheels: Manually lockable. Lock the wheels when the lift is parked.
- 15** Front wheels: Lock automatically when the platform is raised.
- 16** Connection for battery charger: 24 V DC, max. 3 A.
- 17** Battery charger: Connect to socket (16) on the lift and connect the plug to 230 V.




After use: Switch off the lift (4) and start charging (17). Lock the lift with the key (3) to prevent unauthorized use.



Translation of the original instructions in Swedish

SAFELIFT[®]

 Made in Sweden

ADDRESS

Safelift Sweden AB
Kvarnvägen 14
SE-352 41 Växjö
Sweden

WEBSITE

www.safelift.se

E-MAIL

info@safelift.se